



Fissatrice Elettrica Electric Tacker

Mod. ME 30 G.B.
Cod. 0215110

Rif.No.	Codice / Code
1+28+24	49061
2	51002
3+4	49066
5+9+10	49012
6	70350
7	40002
8	70351
11	70353
12	70342
13	54005
14	70341
15	70344
16	62098
18	70343
19	43617
20	62097
21	55009
22	42769
23	50004
25	70360
26	70357
27	62095
29	40012
30	70352
31	50208
32+33	49026
34	42177
35	40130
36	72458
37	50233

Rif.No.	Codice / Code
16 + 19 + 20 + 21 + 22 + 25 + 26 + 27	49077
11+19+ 36+ 37	49078
11 + 16 + 19 + 20 + 21 + 22 + 25 + 26 + 27 + 36 + 37	49079

● **RICAMBI CONSIGLIATI**
RECOMMENDED SPARE PARTS
PIECES DE RECHANGE RECOMMANDEES
EMPFOHLENE ERSATZETEILE
REPUESTOS ACONSEJADOS

