


PARTS DRAWING

CN45



CN45 PARTS LIST

NO	ITEM	NO	ITEM
1	SCREW	51	TRIGGER VALVE CAGE
2	EXHAUST COVER HOLDER	52	O-RING
3	EXHAUST COVER	53	O-RING
4	EXHAUST FILTER A	54	TRIGGER VALVE UPPER
5	EXHAUST FILTER B	55	TRIGGER VALVE PLUNGER
6	BOLT	56	O-RING
7	CYLINDER CAP	57	SPRING
8	CYLINDER CAP GASKET	58	O-RING 6X1.8
9	BACK BUMPER	59	TRIGGER VALVE STEM
10	EXHAUST SEAL	60	O-RING 6X1.8
11	COMPRESSION SPRING	61	RETAINER RING B
12	BUMPER A	62	CHECK PLATE PIN
13	O-RING	63	TORSION SPRING
14	BUMPER B	64	CHECK PLATE
15	O-RING	65	RETAINER RING A
16	CYLINDER RING	66	FEED PAWL
17	O-RING (1)	67	SPRING
18	CYLINDER	68	FEED PAWL PIN
19	O-RING (2)	69	DOOR PIN
20	CYLINDER SEAL	70	NOSE
21	BODY	71	DOOR
22	RUBBER HANDLE GRIP	72	CHECK PAWL PIN
23	PIN 2X8	73	CHECK PAWL
24	MODE SWITCH POSITIONER	74	SPRING
25	SPRING	75	SIDE SHIELD
26	SAFETY MODE SWITCH	76	PIN
27	TRIGGER PLUNGING PLATE	77	DOOR LATCH
28	TRIGGER	78	DOOR SPRING
29	PIN	79	O-RING (1)
30	RUBBER RETAINER	80	FEED PISTON
31	TRIGGER PIN	81	O-RING (2)
32	O-RING	82	SPRING
33	BOLT	83	FEED PISTON BUMPER
34	SAFETY UPPER	84	FEED CYLINDER CAP
35	SPRING	85	LOOP RETAINER
36	SAFETY UPPER GUIDE	86	END CAP SEAL
37	PIN	87	END CAP
38	DEPTH CONTROL WHEEL	88	BOLT M5X25
39	SAFETY LOWER GUIDE	89	MAGAZINE COVER
40	BOLT	90	SPRING HOLDER UPPER A
41	O-RING	91	SPRING
42	LOOP RETAINER	92	NAIL SUPPORT PLATE
43	HEX NUT	93	SPRING HOLDER LOWER B
44	SATETY LEVER	94	MAGAZINE
45	BUTTON RING	95	BOLT M5X35
46	DRIVER BLADE	96	NUT M5
47	DRIVER PISTON	97	MAGAZINE PIN
48	O-RING	98	NOSE SHIELD COVER
49	SPRING	99	DUST COVER
50	PIN		